

LAPCO Shirts Sizing Chart

MENS ALPHA TO NUMERIC SHIRT SIZING

To find your shirt size, use your neck, chest, and sleeve measurement. Sleeve length can be found by measuring from the center back of your neck to the end of your shoulder at the top of your arm then to your wrist where you would like your shirt cuff to sit.

IXXX7 / IBW7 / IHV7C2 / IHV7C3 / DH6 / GOSAC7 / GOS6 / GOS7 / LS / DS / 850									
Alpha Size	SM	MED	LAR	XL	2XL	3XL	4XL	5XL	6XL
Neck Size	14.5-15	15.5-16	16.5-17	17.5-18	19	20	22	23	24
Chest Measurement	34-36	38-40	42-44	46-48	50-52	54-56	58-60	62-64	66-68
SHO Sleeve	31-32	32-33	33-34	34	35	35	36	36	36
REG Sleeve	32-33	33-34	34-35	35	36	36	37	37	37
LON Sleeve	33-34	34-35	35-36	36	37	37	38	38	38
XLO Sleeve	34-35	35-36	36-37	37	38	38	39	39	39

Short sizes are 2" shorter than Regular sizes in the torso.
Long sizes are 2" longer than Regular sizes in the torso.
Extra Tall sizes are 5" longer than Regular sizes in the torso.